



PENTALIFT EQUIPMENT CORPORATION

PENTALIFT HFR32
VEHICLE RESTRAINT

OWNERS MANUAL

SERIAL NUMBER : _____

Individual Serial Number(s) must be filled out by the user for future reference.






THIS MANUAL IS AN IMPORTANT DOCUMENT
IT SHOULD BE KEPT WITH THE MACHINE OR LOCATION WHERE READILY AVAILABLE TO OPERATORS AND MAINTENANCE PERSONNEL FOR REFERENCE PURPOSE. DO NOT INSTALL, OPERATE OR SERVICE THIS PRODUCT UNLESS YOU HAVE READ AND FULLY UNDERSTAND THE ENTIRE CONTENTS OF THIS MANUAL. FAILURE TO DO SO MAY RESULT IN PROPERTY DAMAGE, BODILY INJURY OR DEATH. KEEP THIS MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE.

SAFETY INFORMATION AND WARNINGS

DANGER

READ THESE SAFETY PRACTICES BEFORE INSTALLING, OPERATING OR SERVICING THE VEHICLE RESTRAINT. FAILURE TO FOLLOW THESE SAFETY PRACTICES MAY RESULT IN PROPERTY DAMAGE, BODILY INJURY OR DEATH.

THE OPERATION OF THIS EQUIPMENT IS SUBJECT TO CERTAIN HAZARDS THAT CAN BE PROTECTED AGAIN ONLY BY THE EXERCISE OF CARE AND COMMON SENSE AND NOT BY MECHANICAL MEANS. IT IS, THEREFORE, ESSENTIAL TO HAVE COMPETENT, QUALIFIED OPERATORS TRAINED IN THE SAFE OPERATION AND CARE OF THIS TYPE OF EQUIPMENT. ALL PERSONNEL MUST COMPLETELY UNDERSTAND THIS SAFETY INFORMATION BEFORE WORKING ON OR NEAR THIS EQUIPMENT.

1.  **DANGER** BEFORE DOING ANY INSTALLATION, MAINTENANCE, INSPECTION OR TROUBLE SHOOTING, BARRICADE ALL AREAS FROM TRAFFIC AROUND THE WORK AREA IN (AND OUTSIDE IF APPLICABLE) FOR SAFETY AND POST APPROPRIATE WARNING SIGNS.
2.  **DANGER** BEFORE DOING ANY ELECTRICAL WORK, BE CERTAIN THAT THE POWER IS DISCONNECTED WITH A FUSED DISCONNECT, PROPERLY TAGGED AND LOCKED FUSED DISCONNECT AND LOCKOUT DEVICE (SUPPLIED AND INSTALLED BY OTHERS) MUST MEET WITH ALL APPLICABLE CODES AND REGULATIONS. ALL ELECTRICAL WORK MUST BE PERFORMED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH ALL APPLICABLE CODES AND REGULATIONS.
3.  **WARNING** IT IS THE RESPONSIBILITY OF OTHERS TO ENSURE THE PROPER MOUNTING OF A WALL MOUNTED EQUIPMENT SUCH AS REMOTE POWER UNITS, CONTROL PANEL LIGHT PACKAGES AND TO ENSURE THAT THE MOUNTING SURFACE IS CAPABLE OF FULLY SUPPORTING THE LOADS GENERATED BY THE EQUIPMENT.
4. Do not load/unload any truck without visually confirming that the vehicle restraint has securely engaged the truck's R.I.G. (Rear Impact Guard) and the appropriate signal lights are illuminated as indicated by the operating instructions in the Owners Manual and on the control panel. If the vehicle restraint fails to engage the truck's R.I.G. for any reason, be certain to restrain the truck with appropriate alternate means and to follow the other procedures listed in this manual before proceeding with any loading/unloading.
5. Never stand between the dock and a truck.
6. Stay clear of operating path at all times.
7. When not in use, the restraint must always be in the stored position.
8. Regular inspection and maintenance must be performed to keep the equipment in proper operating condition in accordance with the detailed instructions in this manual. (See the MAINTENANCE & LUBRICATION section of this manual on page 14.)
9. Assure that the equipment is not used by anyone if you believe that any part of it might be in disrepair (e.g. loose or leaking hoses, bent structural members, broken welds, etc.). See Warranty Section.
10. If you have any questions, contact your immediate supervisor or your authorized Pentalift representative for assistance.
11. Do not use the VEHICLE RESTRAINT while under the influence of drugs or alcohol.

DANGER

This is the highest level statement. Failure to follow the listed instructions will most likely result in severe injury or death.

WARNING

This is a statement of serious hazard. Failure to follow the listed instructions could place the operator at risk of serious injury or death.

CAUTION

The statements used with this level of warning deal with a safe operating procedure. If the procedure is ignored, the possibility of personal injury may exist.

IMPORTANT

This statement draws attention to a procedure that needs to be followed to prevent machine or property damage.

OWNER RESPONSIBILITY

The Owner's Responsibilities include the following:

- 4.1 The owner should recognize the inherent danger of the interface between dock and transport vehicle. The Owner should, therefore, train and instruct operators in the safe use of dock leveling devices in accordance with information provided in Section 4.1.2.
- 4.2 When a transport vehicle is positioned as closely as practicable to a dock leveling device, there shall be at least 4" (100 mm) of overlap between the front edge of the lip and the edge of the floor or sill of the transport vehicle."
- 4.3 Nameplates, cautions, instructions and posted warnings shall not be obscured from the view of operating or maintenance personnel for whom such warnings are intended.
- 4.4 Manufacturer's recommended periodic maintenance and inspection procedures in effect at date of shipment shall be followed, and written records of performance of these procedures should be kept.
- 4.5 Dock leveling devices that are structurally damaged or have experienced a sudden loss of support while under load, such as might occur when a transport vehicle is pulled out from under the dock leveling device, shall be removed from service, inspected by the manufacturer's authorized representative, and repaired as needed before being placed back in service.
- 4.6 The manufacturer shall supply replacement nameplates, caution or instruction labels and operating and maintenance manuals upon request of the owner. The owner shall see that all nameplates and caution and instruction markings or labels are in place and legible and that the appropriate operating and maintenance manuals are provided to users.
- 4.7 Modifications or alterations of dock leveling devices shall be made only with written permission of the original manufacturer. These changes shall be in conformance with all applicable provisions of this standard and shall be at least as safe as the equipment was before modification. These changes shall also satisfy all safety recommendations of the original equipment manufacturer for the particular application of the dock leveler.
- 4.8 When industrial trucks are driven on and off transport vehicles during the loading and unloading operation, the brakes on the transport vehicle shall be applied and wheel chocks or positive restraints that provide the equivalent protection of wheel chocks engaged.
- 4.9 In selecting dock leveling devices, it is important to consider not only present requirements but also future plans or adverse environments.
- 4.10 The dock leveler should never be used outside its vertical working range or vertical lifting range or outside the manufacturer's labeled rated capacity. It must also be compatible with the loading equipment and other conditions relating to the dock.

NOTE: The MH30 Committee recognizes the devices intended to secure a transport vehicle to a loading dock by mechanical means. The NHTSA Standard 49CFR ch.V 571.223 specifies the strength of the rear impact guard and 49 CFR Ch.V 571.224 specifies the size and locations of the rear impact guard. It is, therefore, recommended that users of such positive restraint devices review:

- The means of attachment to the transport vehicle
- The strength of the overall connection
- The proper coordination of the actuation of devices with any signaling system used
- The need to use wheel chocks



Unless specifically agreed to in writing by Pentalift Equipment Corporation at the time the equipment is ordered and prior to the equipment's manufacture, this equipment is sold as a complete package. It is not to be altered, changed or added to in any way or form, in its configuration and function, without the written permission of Pentalift Equipment Corporation.


Requested by a customer, Pentalift Equipment Corporation is not supplying all or some of the power unit and / or control components for the equipment's application. The power unit and controls constitute important safety and functional aspects of equipment. It is the customer's responsibility to address the operational and safety issues associated with providing the wired controls and power units to satisfy the operational and safety requirements of the equipment.

The customer's decision to supply all or some of these components indicates that the customer is taking full responsibility for and all possible operational, safety and liability issues associated to the product and its configuration. The customer also agrees to absolve Pentalift Equipment Corporation from any and all possible operation, safety and liability issues.

TABLE OF CONTENTS

PRODUCT REGISTRATION	
SAFETY INFORMATION AND WARNINGS	
OWNER RESPONSIBILITY	
TABLE OF CONTENTS	
SAFETY LABELING	
INSTALLATION INSTRUCTIONS	
WELDING REFERENCE INFORMATION	
OPTIONAL EXTENSION PLATE INSTALLATION INSTRUCTIONS	
ELECTRICAL INSTALLATION INSTRUCTIONS	
OPERATION AND PERFORMANCE CHECK	
OPERATING INSTRUCTIONS	
DOCK VACANT / READY TO RECEIVE A VEHICLE	
TRAILER IN POSITION	
LOADING / UNLOADING COMPLETE	
R.I.G. CANNOT BE ENGAGED BY RESTRAINT	
LOADING / UNLOADING COMPLETE	
MAINTENANCE & LUBRICATION	
TROUBLE SHOOTING GUIDE	
RESTRAINT ADJUSTMENTS	
SETTING THE DOWN TRAVEL LIMIT SWITCH LOWERED POSITION:	
SIGNAL BAR SWITCH ADJUSTMENTS	
ADJUSTMENT OF RESTRAINT ENGAGE HEIGHT	
REPLACEMENT PARTS	
RESTRAINT REPLACEMENT PARTS LIST	
CONTROL PANEL REPLACEMENT PARTS	
SINGLE PHASE	
THREE PHASE	
DELUXE OUTSIDE LIGHT REPLACEMENT PARTS	
REPLACEMENT SIGNS	
LIST OF ILLUSTRATIONS	
PENTALIFT EQUIPMENT CORPORATION WARRANTY	

SAFETY LABELING



sure that all labeling is in place and intact when the unit is received. If any of the safety labels or decals are missing or illegible, contact your Pentalift representative for immediate replacement.

NOTE: It is the owner's responsibility to assure that all safety labeling remains legible and in its original position throughout the life of the product. If any of the safety labels or decals are missing or illegible, contact your Pentalift representative for immediate replacement. Inspection shall be done during regular maintenance and lubrication (see Maintenance Section, page 14)

re-order labels and decals, use the following part numbers:

ITEM	PART NO.	DESCRIPTION
1	250-2341	"CAUTION Stay clear of equipment..."
2	250-1143	"Pentalift"
3	250-2368	Specification Plate

NOTE: State Model # and Serial # when ordering replacement parts.






INSTALLATION INSTRUCTIONS




DO NOT INSTALL, OPERATE OR SERVICE THIS PRODUCT UNLESS HAVE READ AND FULLY UNDERSTAND THE ENTIRE CONTENTS OF THIS MANUAL. FAILURE TO DO SO MAY RESULT IN PROPERTY DAMAGE, BODILY INJURY OR DEATH.

IMPORTANT PREPARATION PRIOR TO INSTALLATION

Follow all installation instructions in the precise consecutive order that they are written. If the equipment can be installed in the order as outlined below, contact Pentalift Equipment Corporation for written instructions or to proceed. Do not proceed with an alternate installation method unless written confirmation has been provided by Pentalift Equipment Corporation.

1.  BEFORE DOING ANY INSTALLATION, MAINTENANCE, INSPECTION OR TROUBLE SHOOTING, BARRICADE ALL AREAS FROM TRAFFIC AROUND THE WORK AREA INSIDE (AND OUTSIDE IF APPLICABLE) FOR SAFETY AND POST APPROPRIATE WARNING SIGNS.
2.  BEFORE DOING ANY ELECTRICAL WORK, BE CERTAIN THAT THE POWER IS DISCONNECTED WITH A FUSED DISCONNECT, PROPERLY TAGGED AND LOCKED OUT. FUSED DISCONNECT AND LOCKOUT DEVICE (SUPPLIED AND INSTALLED BY OTHERS) MUST MEET WITH ALL APPLICABLE CODES AND REGULATIONS. ALL ELECTRICAL WORK MUST BE PERFORMED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH ALL APPLICABLE CODES AND REGULATIONS.
3.  MAKE SURE LIFTING AND SLINGING DEVICES ARE OF SUFFICIENT CAPACITY USED IN THE CORRECT MANNER AND ARE IN GOOD WORKING ORDER. ALL LIFTING, POSITIONING AND INSTALLATION, AS WELL AS THE BREAK-IN AND PERFORMANCE CHECK, IS TO BE DONE BY QUALIFIED PERSONNEL TRAINED AND EXPERIENCED IN THE NECESSARY SAFETY PROCEDURES.
4.  IT IS THE RESPONSIBILITY OF OTHERS TO ENSURE THE PROPER MOUNTING OF ANY WALL MOUNTED EQUIPMENT SUCH AS REMOTE POWER UNITS, CONTROL PANELS AND LIGHT PACKAGES AND TO ENSURE THAT THE MOUNTING SURFACE IS CAPABLE OF FULLY SUPPORTING THE LOADS GENERATED BY THE EQUIPMENT.
5.  THIS RESTRAINT IS DESIGNED TO OPERATE WITH THE FACE OF THE DOCK BUMPERS EXTENDED 4" PAST THE POSITION OF THE BACK PLATE OF THE RESTRAINT ONCE IT IS INSTALLED. THIS DIMENSION RELATIONSHIP IS CRITICAL TO ASSURING THE PROPER OPERATIONAL POSITIONING OF THE RESTRAINT. PRIOR TO COMMENCING WITH THE INSTALLATION, CONFIRM THAT THE ABOVE NOTED RELATIONSHIP BETWEEN THE DOCK BUMPER AND THE RESTRAINT WILL EXIST ONCE THE INSTALLATION IS COMPLETED. ONCE THIS IS CONFIRMED, COMMENCE THE INSTALLATION. IF THE PROPER RELATIONSHIP WILL NOT EXIST, A RESTRAINT INSTALLATION EXTENSION PLATE MAY BE REQUIRED. CONSULT YOUR AUTHORIZED REPRESENTATIVE FOR ASSISTANCE.



Assure concrete and anchor bolts have sufficient strength to meet the draw pull forces which will be applied simultaneously. (See Figure 2, page 4).



- Assure that the required conduits are in place (see Figure 7, page 7).
- Mark the centerline of the dock and the center line of the restraint back plate.


9. Position the HFR32 by matching the centerline of the dock and the center line of the restraint back plate (Figure 3, page 5).

IMPORTANT: The restraint must be at finished driveway level and flush with the foundation wall



10. Remove the guard assembly from the restraint (see Figure 4, page 5).
11. If the wall and/or ground are not square with respect to the back plate and the bottom plate of the restraint, metal shims must be inserted to prevent the back plate from twisting during lagging to the wall (see Figure 3, page 5). Shims must be placed under the bottom plate below the hydraulic cylinder and at the front end of the bottom plate for proper support.
12. If the dock face is equipped with a cast in weld plate, proceed to step 14. Otherwise, drill the required holes into the foundation wall, using the back plate of the restraint as a template.
13. Recommended fasteners are $\frac{3}{4}$ " diameter x minimum 7" long wedge anchors with a minimum shear value of 18,500 lbs (8,390 kg), and a tension value of 16,400 lbs (7,440 kg). Torque to manufacturer's specifications.

If a weld plate has been pre-cast into the foundation, apply a 3/8" fillet weld 3" long at 6" intervals around the two sides and the top of the back plate. Also, weld all slots in the back plate to the foundation weld plate. For more information, see WELDING REFERENCE INFORMATION on page 7 as well as Figure 5 on page 6.




Weld all shims in a stack to each other as well as to the back plate.

Mount the power unit horizontally with the reservoir breather facing up (see Figure 6, page 1).

Install the control panel and interior safety warning sign in a location that assures an unobstructed view at all times. The installation location must ensure the complete legibility of the operating instructions during the operation of all loading dock equipment, including the fork lifts.

Feed the hydraulic hose through the conduit from the power unit to the cylinder on the restraint, connect and secure.



OPTIONAL EXTENSION PLATE INSTALLATION INSTRUCTIONS

⚠ DANGER

BEFORE DOING ANY INSTALLATION, MAINTENANCE, INSPECTION OR TROUBLE SHOOTING, BARRICADE ALL AREAS FROM TRAFFIC AROUND THE WORK AREA INSIDE (AND OUTSIDE IF APPLICABLE) FOR SAFETY AND POST APPROPRIATE WARNING SIGNS.

⚠ WARNING

THIS RESTRAINT IS DESIGNED TO OPERATE WITH THE FACE OF THE DOCK BUMPER EXTENDED 4" PAST THE POSITION OF THE BACK PLATE OF THE RESTRAINT ONCE IT IS INSTALLED. THIS DIMENSION RELATIONSHIP IS CRITICAL ASSURING THE PROPER OPERATIONAL POSITIONING OF THE RESTRAINT. THE OPTIONAL TENSION IS REQUIRED ONLY WHEN THIS RELATIONSHIP BETWEEN THE DOCK BUMPER AND THE STRAINT WILL NOT EXIST ONCE THE INSTALLATION IS COMPLETED. ONCE IT IS CONFIRMED THAT RESTRAINT INSTALLATION EXTENSION PLATE IS REQUIRED, FOLLOW THESE INSTRUCTIONS TO STALL IT PROPERLY. (CONSULT YOUR AUTHORIZED PENTALIFT REPRESENTATIVE FOR SISTANCE IN ACQUIRING THE CORRECT EXTENSION.)

Assure that the required conduits are in place (See Figure 7, Page 7).

Assure concrete has sufficient strength to meet the draw pull forces which will be applied (See Figure 2, page 4).

Mark the center line of the dock, the center line of the restraint back plate between the mounting holes and the center line of the extension back plate.

If a cast in weld plate has been installed in the dock face, proceed to instruction 9.

Center the extension back plate on the center line of the dock.

If required, shim behind the extension back plate (as shown in Figure 8, page 8) to ensure the extension back plate is plumb and flush with the foundation wall.





Figure 8: Extension Shim Locations

Drill required holes into the foundation using the extension plate as a template.

Recommended fasteners are 3/4" diameter x minimum 7" long wedge anchors with a minimum shear value of 18,500 lbs (8,390 kg), and tension value of 16,400 lbs (7,440 kg). Torque to manufacturers' specifications.

9. Weld the extension tube to the restraint backplate, centered both vertically and horizontally between the mounting holes, as shown in Figure 9, page 9, and weld using a minimum $\frac{1}{4}$ " leg on the welds and 2" for welds on 4" centers. (Refer to the WELDING REFERENCE INFORMATION on page 7.)



10. Position the restraint, complete with extension tube, centered vertically and horizontally to the extension
11. If required, shim beneath the restraint as shown in Figure 8, Page 8.
12. Weld the extension tube to the extension back plate (or cast-in weld plate) using the same weld specific as noted for welding the extension tube to the back plate of the restraint in Figure 9, page 9.
13. Weld all shims in a stack to each other as well as to the back plate and/or bottom plate.
14. Lubricate all pivot points (see MAINTENANCE & LUBRICATION on Page 14).
15. Clean and Paint Welds.
16. Test operation (see OPERATION AND PERFORMANCE CHECK on Page 11).
17. Check the raised height of the restraint and ensure that it is properly set. If adjustment is required follow adjustment instructions. (see ADJUSTMENT OF RESTRAINT ENGAGE HEIGHT on page 20).

OPERATION AND PERFORMANCE CHECK



WARNING SIGNS.

BEFORE DOING ANY INSTALLATION, MAINTENANCE, INSPECTION OR TROUBLESHOOTING, BARRICADE ALL AREAS FROM TRAFFIC AROUND THE WORK AREA INSIDE (AND OUTSIDE IF APPLICABLE) FOR SAFETY AND POST APPROPRIATELY.



BEFORE DOING ANY ELECTRICAL WORK, BE CERTAIN THAT THE POWER IS DISCONNECTED WITH A FUSED DISCONNECT, PROPERLY TAGGED AND LOCKED OUT. FUSED DISCONNECT AND LOCKOUT DEVICE (SUPPLIED AND INSTALLED BY OTHERS) MUST MEET WITH ALL APPLICABLE CODES AND REGULATIONS. ALL ELECTRICAL WORK MUST BE PERFORMED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH APPLICABLE CODES AND REGULATIONS.



FAILURE TO CONFIRM THE CORRECT OPERATION OF THE VEHICLE RESTRAINT IN ACCORDANCE WITH THESE INSTRUCTIONS MAY RESULT IN PROPERTY DAMAGE, BODILY INJURY OR DEATH.

NOTE: IN SOME CASES THERE IS A CONSIDERABLE AMOUNT OF TIME BETWEEN THE SHIPMENT DATE AND USE OF YOUR VEHICLE RESTRAINT. THIS INITIAL BREAK-IN AND PERFORMANCE CHECK SHOULD BE PERFORMED BEFORE YOU BEGIN REGULAR USE OF YOUR VEHICLE RESTRAINT TO ENSURE THAT IT IS OPERATING PROPERLY.

1. Ensure the vehicle restraint has been returned to the **STORED** position (hook fully lowered). The **inside** light and the **outside GREEN** light must be illuminated.
2. Turn the selector switch to the **"ENGAGE"** position. The Restraint must move to the **FULLY** raised position. The **inside red** light must be illuminated while the **outside red** light is also illuminated and the audible alarm must be sounding. (See Figure 15, page 13.)
3. **Depress and hold the signal bar** (see Figure 21, page 19). This will simulate a truck's R.I.G. The **inside GREEN** light must be illuminated. The **outside RED** light must be illuminated and the audible alarm must turn off.
4. To test the **OVERRIDE** feature, ensure the signal bar is not depressed and follow the entire sequence outlined in Step 2. With the restraint in the fully raised position and with the audible alarm sounding, turn selector switch to the **"OVERRIDE"** position. The hooking arm will automatically return to the low position, and the audible alarm will be silenced. The **outside RED** light must be illuminated and the **inside YELLOW** light must be illuminated. (see Figure 16 and Figure 17, Page 13).
5. Replace any burnt out light bulbs on the control panel or defective LED modules immediately.
6. Lubricate all pivot points as outlined in the **MAINTENANCE & LUBRICATION** Section on page 14.

The above steps describe and confirm the correct operation of this important piece of safety equipment. If the unit you have does not meet the requirements listed above, discontinue its use and/or repair it immediately. See the Troubleshooting section to correct problems. Contact your Pentallift representative for any required assistance.

OPERATING INSTRUCTIONS

⚠ DANGER

USE BY UNTRAINED PEOPLE CAN RESULT IN PROPERTY DAMAGE, BODILY INJURY OR DEATH. READ, KNOW, AND OBEY ALL OPERATING INSTRUCTIONS AND SAFETY INFORMATION. FOLLOW ALL OSHA REGULATIONS REGARDING THE USE OF THIS EQUIPMENT. DO NOT USE THE VEHICLE RESTRAINT IF ANY PART OF IT LOOKS BROKEN IF IT DOES NOT SEEM TO OPERATE PROPERLY. IF REPAIRS ARE NEEDED, CONTACT YOUR NEAREST ITALIFT REPRESENTATIVE.

DOCK VACANT / READY TO RECEIVE A VEHICLE

When the selector switch is set at "DISENGAGE" Position the inside control panel red light is illuminated and the side green light is illuminated, indicating that the dock is ready for truck arrival or departure.




Figure 10: Inside Light Red




Figure 11: Restraint Lowered

TRAILER IN POSITION

When the trailer is centered in front of the loading dock and parked tight against both dock bumpers, the operator turns the SELECTOR SWITCH TO "ENGAGE" POSITION. The outside red light will illuminate and the restraint will engage until the signal bar makes contact with the truck's R.I.G. (If audible alarm sounds see "R.I.G. CANNOT BE ENGAGED BY RESTRAINT" on page 13). With the R.I.G. properly engaged, the inside control panel green light illuminates. Visually confirm that the restraint has properly engaged the rear impact guard before loading or unloading. If unable to properly engage the vehicle with the restraint, other suitable means must be used to restrain the vehicle.




Figure 12: Inside Light Green




Figure 13: Vehicle in Position

LOADING / UNLOADING COMPLETE

When loading/unloading is complete, turn the SELECTOR SWITCH TO "DISENGAGE" POSITION. Illumination of the lights will reverse (inside red and the outside green will illuminate) and the truck is free to depart.

R.I.G. CANNOT BE ENGAGED BY RESTRAINT

If the restraint fails to properly engage the R.I.G. an AUDIBLE ALARM WILL SOUND. Both the inside light and the outside light will remain red. Confirm that the trailer is centered with the loading dock and parked tight at both bumpers; and that the R.I.G. is not damaged, missing or located too far toward the rear trailer axle for the restraint to properly engage it.




Figure 15: Inside Light Red and Alarm Sounding




Figure 14: R.I.G. Not Secure

If engagement by the restraint is not possible, SECURE THE TRAILER BY OTHER MEANS. Turn the SELECTOR SWITCH TO THE "OVERRIDE" POSITION. The outside red light will remain red, the inside yellow light will illuminate. The inside red light and audible alarm will turn off. The restraint will return to its lowered position.




Figure 16: Inside Light Yellow




Figure 17: Secure Vehicle by Other Means

LOADING / UNLOADING COMPLETE

If the trailer was secured by other means, remove them at this time. Immediately turn the selector switch to "DISENGAGE" Position. The inside red and outside green light will be illuminated. The truck is free to depart the dock is ready to receive another vehicle.

NOTE: If the vehicle R.I.G. has moved forward during loading / unloading (truck "creep" has occurred), then draw pull force and friction holding the restraint in the engaged position. If the restraint will not release, pull the trailer back toward the dock to release the tension on the restraint, allowing it to lower.

MAINTENANCE & LUBRICATION

DANGER

ONLY TRAINED AND QUALIFIED PERSONNEL SHOULD PERFORM INSPECTION OR MAINTENANCE AND SERVICE PROCEDURES.

DANGER

BEFORE DOING ANY INSTALLATION, MAINTENANCE, INSPECTION OR TROUBLE SHOOTING, BARRICADE ALL AREAS FROM TRAFFIC AROUND THE WORK AREA INSIDE (AND OUTSIDE IF APPLICABLE) FOR SAFETY AND POST APPROPRIATE WARNING SIGNS.

DANGER

BEFORE DOING ANY ELECTRICAL WORK, BE CERTAIN THAT THE POWER IS DISCONNECTED WITH A FUSED DISCONNECT, PROPERLY TAGGED AND LOCKED OUT. FUSED DISCONNECT AND LOCKOUT DEVICE (SUPPLIED AND INSTALLED BY OTHERS) MUST MEET WITH ALL APPLICABLE CODES AND REGULATIONS. ALL ELECTRICAL WORK MUST BE PERFORMED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH ALL APPLICABLE CODES AND REGULATIONS.

DANGER

THE RELIEF VALVE ON THE POWER UNIT IS PRESET AT THE FACTORY. IT IS AN IMPORTANT SAFETY DEVICE. DO NOT ADJUST OR REMOVE THE RELIEF VALVE.

CLEANING: The face of a loading dock is generally one of the dirtiest areas in a facility. Dirt and debris fall from loading dock into and on the restraint area. The **HFR32 Vehicle Restraint** is designed to have a long trouble-free operating life in this type of condition. However, the area around the restraint must be cleaned on a regular basis. Frequency will vary depending on the conditions at each individual location. Initially, cleaning must be done on a weekly basis. Thereafter, the frequency of cleaning can be adjusted to suit the specific individual installation conditions. Snow and ice must be cleaned away as soon as it accumulates.

CHECK ON A DAILY BASIS:

Replace burnt out light bulbs on the control panel, or defective LED modules, immediately. Due to the continuous use of dock traffic light systems and the life span of light bulbs, daily inspection of the light system should be performed. Spare light bulbs and an LED module should be kept on hand at all times for immediate replacement. Ensure that the proper lens color is in the proper position after checking bulbs and LED modules. Check the signal arm spring to ensure that it is not broken (See **REPLACEMENT PARTS** on page 21, item #19). Replace broken signal arm springs immediately. **USE ONLY GENUINE PENTALIFT REPLACEMENT PARTS**

Follow the steps listed in the **OPERATION AND PERFORMANCE CHECK** Section of this manual. (See page 19)

Check the raised height of the restraint and ensure that it is properly set. If adjustment is required follow the adjustment instructions. (see **ADJUSTMENT OF RESTRAINT ENGAGE HEIGHT** on page 20)

NOTE: Read the **SAFETY INFORMATION AND WARNINGS** before servicing the **HFR32 Vehicle Restraint**. (See page 11.)


NOTE: It is the owner's responsibility to assure that all labeling remains legible and in its original position throughout the life of the product (See **Safety Labeling Section, Page 2**).

NOTE: Inspect equipment for protective coatings (i.e. paint) that have deteriorated or been removed. Prepare affected area and reapply protective coating as required.

NOTE: At every maintenance interval, inspect the HFR32 Vehicle Restraint for any damaged or worn parts. If any damaged or worn parts are found, discontinue use of the vehicle restraint and/or repair immediately.

The recommended lubrication service interval is every 30 days or at a greater frequency as required in severe environments. For maximum bearing life, the recommended lubricant is NLGI Grade 2 grease with EP and MOS2 additives.

Also note that the power unit fluid should be changed every 12 months. The required hydraulic oil is Dexron III Automatic Transmission Fluid.



TROUBLE SHOOTING GUIDE

NOTE: This equipment has been fully tested and confirmed to be operational at the factory. Historically, majority of operating problems are caused by unnecessary tampering by unqualified personnel. To conform to the terms of the Warranty, contact your authorized Pentalift representative if you are having difficulty with the VEHICLE RESTRAINT during the warranty period. Do not risk voiding the warranty tampering with the equipment.

DANGER

ONLY TRAINED AND QUALIFIED PERSONNEL SHOULD PERFORM INSPECTION OR MAINTENANCE AND SERVICE PROCEDURES.

DANGER

THE RELIEF VALVE ON THE POWER UNIT IS PRESET AT THE FACTORY. IT IS AN IMPORTANT SAFETY DEVICE. DO NOT ADJUST OR REMOVE THE RELIEF VALVE.

DANGER

BEFORE DOING ANY INSTALLATION, MAINTENANCE, INSPECTION OR TROUBLE SHOOTING, BARRICADE ALL AREAS FROM TRAFFIC AROUND THE WORK AREA INSIDE (AND OUTSIDE IF APPLICABLE) FOR SAFETY AND POST APPROPRIATE WARNING SIGNS.

DANGER

BEFORE DOING ANY ELECTRICAL WORK, BE CERTAIN THAT THE POWER IS DISCONNECTED WITH A FUSED DISCONNECT, PROPERLY TAGGED AND LOCKED OUT. FUSED DISCONNECT AND LOCKOUT DEVICE (SUPPLIED AND INSTALLED BY OTHERS) MUST MEET WITH ALL APPLICABLE CODES AND REGULATIONS. ALL ELECTRICAL WORK MUST BE PERFORMED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH ALL APPLICABLE CODES AND REGULATIONS.

IMPORTANT: See page 14 for recommended hydraulic oil.

Restraint will not rise when the selector switch is turned to the "II" (Raise) position:

- Confirm that the signal bar limit switch has not been depressed (see Figure 21, page 19).
- Check the signal bar spring is in place (see Figure 21, page 19).
- Check signal bar limit switch adjustment on signal bar (see Figure 21, page 19).
- Check that hydraulic fluid level is approximately two inches from the top of the reservoir when the restraint is completely lowered.
- Examine all moving parts for obstructions or binding.
- Check all wiring and hydraulic connections.
- Confirm that power is reaching the power unit.
- Check the timer in the control box and verify time and mode settings. The top dip switch must be toggled to the right and the second down toggles to the left for the 10 second range. The third dip switch must be toggled to the right and the fourth toggled to the left for the off setting. (See Figure 19, page 16) The timer should be set at 6 seconds.
- If the problem cannot be solved, consult your authorized Pentalift representative.




Figure 19: Time and Mode Settings

Restraint rises but has a jerking movement:

- Check that hydraulic fluid level is approximately two inches from the top of the reservoir when the restraint is completely lowered.
- Check signal bar limit switch adjustment (see Figure 21, page 19).
- If the problem cannot be solved, contact your authorized Pentalift Representative.

ump continues to run when restraint is at the raised position:

- Check the timer in the control box and verify time and mode settings. The top dip switch must be toggled to the right and the second down toggles to the left for the 10 second range. The third dip switch must be toggled to the right and the fourth toggled to the left for the "off" mode setting. (See Figure 19, page 16) The timer should be set at 6 seconds.
- If the problem cannot be solved, contact your authorized Pentalift Representative.

4. The restraint will not raise completely:

- Check that hydraulic fluid level is approximately two inches from the top of the reservoir when restraint is completely lowered.
- Check for any obstructions or binding to ensure the hook can move freely.
- Check the timer setting (timer should be set at 6 seconds). Ensure the timer is not shutting pump before the restraint reaches the top of its travel.
- If the problem cannot be solved, contact your authorized Pentalift Representative.

5. The Restraint will not lower:

- Check for any obstructions and binding to ensure the hook can move freely.
- The down travel limit switch lower position setting may need to be reset. See **SETTING THE TRAVEL LIMIT SWITCH LOWERED POSITION**, page 18.
- Check for power to the lowering valve.
NOTE: If the vehicle R.I.G. has moved forward during loading / unloading (truck "creep" occurred), there may be draw pull force and friction holding the restraint in the engaged position. The restraint will not release, move the trailer back toward the dock to release the tension on the restraint, allowing it to lower.
- Ensure lowering extension spring is in place (see item 18, Figure 23, page 21).
- If the problem cannot be solved, contact your authorized Pentalift Representative.

6. The Restraint will not rise.

- Check all wiring.
- Check the timer in the control box and verify time and mode settings. The top dip switch must be toggled to the right and the second down toggles to the left for the 10 second range. The third switch must be toggled to the right and the fourth toggled to the left for the off setting. (See Figure 16) The timer must be set at 6 seconds.
- Check for leaking hose or hydraulic connections.
- Check that hydraulic fluid level is approximately two inches from the top of the reservoir when restraint is completely lowered.
- Confirm that the signal bar limit switch is not activated. (see Figure 21, page 19)
- If the problem cannot be solved, contact your authorized Pentalift Representative.

7. Alarm Sounds and Restraint is not completely raised.

- Check the signal bar wiring and limit switch adjustments.
- Check the timer in the control box and verify time and mode settings. The top dip switch must be toggled to the right and the second down toggles to the left for the 10 second range. The third switch must be toggled to the right and the fourth toggled to the left for the off setting. (See Figure 16) The timer must be set at 6 seconds.
- Check for leaking hose or hydraulic connections.
- Check that hydraulic fluid level is approximately two inches from the top of the reservoir when restraint is completely lowered.
- Confirm that the signal bar limit switch is not activated. (see Figure 21, page 19)
- If the problem cannot be solved, contact your authorized Pentalift Representative.

8. Outside red light remains illuminated and will not change to green.

- Confirm that restraint is able to completely lower. The rear limit switch will not switch the lights unless the restraint hook is completely lowered and in contact with the bottom plate.
- Check down travel limit switch lower position setting. (See **SETTING THE DOWN TRAVEL LIMIT SWITCH LOWERED POSITION**, page 18.)
- Confirm that the signal bar limit switch is not activated. (see Figure 21, page 19)
- If the problem cannot be solved, contact your authorized Pentalift Representative.

If damaged or worn parts are detected upon inspection, replacement must be undertaken **immediately**. The vehicle restraint must not be used until replacement is completed. Parts are readily available from your Pentalift representative.

RESTRAINT ADJUSTMENTS

SETTING THE DOWN TRAVEL LIMIT SWITCH LOWERED POSITION:

⚠ DANGER TO ENSURE THAT THE RESTRAINT IS NOT INADVERTANTLY ACTIVATED WHILE THE FOLLOWING ADJUSTMENTS ARE BEING MADE, BARRICADE ALL AREAS FROM TRAFFIC AROUND THE WORK AREA INSIDE (AND OUTSIDE IF APPLICABLE) FOR SAFETY (PARTICULARLY THE CONTROL BOX LOCATION) AND POST APPROPRIATE WARNING SIGNS.

Remove the guard assembly (see Figure 4, Page 5).

Raise the restraint and place a 1/2" shim under the hooking arm (see Figure 20, page 18).

Lower the restraint onto the 1/2" shim.

Loosen the set screw on the limit switch roller arm.

Turn the roller arm on the post until the roller contacts the hook arm.

Tighten the set screw of the roller arm.

Raise the restraint; remove the 1/4" shim.

Lower the restraint with no shim and confirm the outside green light is illuminated.

Raise the restraint and place a 3/4" shim under the hooking arm.

Lower the restraint onto the 3/4" shim and confirm that the outside red light is illuminated.

NOTE: When the restraint is in the lowered position with **no shim** under the hooking arm, the outside **green** light should be illuminated.

When the restraint is in the lowered position with the **3/4" shim** under the hooking arm, the outside **red** light should be illuminated.

Repeat items b) to f) until this is accomplished.

Remove all shims.

Reinstall the guard assembly.




Figure 20: Setting the Down Travel Limit Switch


RESTRAINT ADJUSTMENT (CON'T)



TO ENSURE THAT THE RESTRAINT IS NOT INADVERTANTLY ACTIVATED WHEN THE FOLLOWING ADJUSTMENTS ARE BEING MADE, BARRICADE ALL AREAS FROM TRAFFIC AROUND THE WORK AREA INSIDE (AND OUTSIDE IF APPLICABLE) FOR SAFETY (PARTICULARLY THE CONTROL BOX LOCATION) AND POST APPROPRIATE WARNING SIGNS.

SIGNAL BAR SWITCH ADJUSTMENT'S

- Raise the restraint.
- Raise the signal bar and confirm that the signal bar spring is in position (see Figure 21, page 19).
- Lower the signal bar and confirm that the signal bar is resting on the signal bar spring.
- Loosen the jam nut and turn the adjusting screw until it is approximately $1/16"$ away from the signal bar limit switch roller.
- Tighten the jam nut while ensuring the adjustment screw does not move.
- Ensure the signal bar limit switch does not bottom out when the signal bar is completely depressed.



M072

Figure 21: Setting the Signal Bar Limit Switch

ADJUSTMENT OF RESTRAINT ENGAGE HEIGHT


NOTE: THE RAISED HEIGHT IS PRESET AT THE FACTORY AND SHOULD NOT REQUIRE ADJUSTMENT.

WARNING: THE OPTIMAL RAISED HEIGHT OF THE RESTRAINT IS 29". IF THE RAISED HEIGHT IS ABOVE 29" DAMAGE TO THE SIGNAL ARM MAY RESULT. IF THE RAISED HEIGHT IS BELOW 29" THE PROTECTION ENVELOPE WILL BE REDUCED AND THE VEHICLE MAY NOT BE RESTRAINED.

If adjustment is required, proceed with the following steps.

RAISED HEIGHT IS TOO LOW: Loosen stop block locking nut. Turn adjustment bolt **in** to **increase** raised height. When proper height is achieved, tighten lock nut against the adjustable stop block. (see Figure 22: Raised Height Adjustment on page 20.)

RAISED HEIGHT IS TOO HIGH: Loosen stop block locking nut. Turn adjustment bolt **out** to **decrease** raised height. When proper height is achieved, tighten lock nut against the adjustable stop block. (see Figure 22: Raised Height Adjustment on page 20.)



REPLACEMENT PARTS


USE ONLY GENUINE PENTALIFT REPLACEMENT PARTS



TO ENSURE PROPER FUNCTIONING, DURABILITY AND SAFETY OF PRODUCT, ONLY GENUINE PENTALIFT REPLACEMENT PARTS MUST BE USED. ALTERING THE PRODUCT FROM ITS ORIGINAL MANUFACTURED CONFIGURATION MUST NOT BE DONE. PENTALIFT EQUIPMENT CORPORATION DISCLAIMS LIABILITY FOR FAILURE TO COMPLY WITH THIS WARNING. WARRANTIES ARE SPECIFICALLY DISCLAIMED IN THE EVENT THE PURCHASER FAILS TO COMPLY WITH THIS WARNING.

To expedite order processing when ordering parts, provide the following information to your Pentalift representative:

1. Model and Serial Number of equipment.
2. Part Number, Description and Quantity.
3. Shipping Instructions.



RESTRAINT REPLACEMENT PARTS LIST **USE ONLY GENUINE PENTALIFT REPLACEMENT PARTS**

<u>ITEM NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	072-0275	Bolt
2	812-0014	Guard Weldment
3	812-0008	Right Arm Weldment
4	812-0015	Left Arm Weldment
5	812-0017	Lower Arm Weldment
6	812-0042	Signal Arm Hook Weldment
7	812-0018	Cylinder Assembly
8	812-0016	Spring Pivot Weldment
9	812-0007	Upper Pin Weldment
10	812-0011	Signal Arm Assembly
11	312-0077	Drilled Hook
12	312-0024	Lower Arm Pin
13	312-0023	Flush Lower Pin
14	312-0027	Upper Arm Pin
15	312-0017	Hook Spacer
16	312-0018	Signal Arm Pin
17	312-0016	Signal Arm Spacer
18	302-0566	Lowering Spring
19	097-0039	Signal Arm Spring (Green)
20	095-0023	Bushing
21	095-0002	Bushing
22	080-0004	Spring Pin
23	080-0001	Spring Pin
24	070-0017	Nylock Nut
25	074-0087	Lock Washer
26	074-0092	Flat Washer
27	074-0056	Flat Washer
28	074-0068	Lock Washer
29	072-0242	Shoulder Bolt
30	072-0001	Hex Bolt
31	072-0118	Machine Screw
32	072-0177	Elevator Screw
33	070-0007	Hex Nut
34	060-0210	Limit Switch
35	060-0686	Limit Switch
36	062-0170	Grease Fitting
37	072-0193	Hex Bolt
38	072-0001	Hex Bolt
39	070-0006	Hex Nut

NOTE: State Model # and Serial # when ordering replacement parts.

CONTROL PANEL REPLACEMENT PARTS

SINGLE PHASE




Figure 24: Single Phase Control Panel

ITEM NO.	PART NO.	DESCRIPTION
1	060-0200	Electrical Enclosure
2	060-772	Red Light Assembly – Includes Fixture, Lens and LED's (Note: Lens may also be ordered separately - see item 3)
3	060-0773	Red Lens
4	060-0201	Green Light Assembly – Includes Fixture, Lens and Bulb (Note: Lens may also be ordered separately – see item 18)
5	250-2377	Decal
6	060-0552	Relay
7	060-0553	Timer
8	060-0551	Relay
9	NOTE	Terminals
	060-0463	Ends
	060-0466	Makers
	060-0464	Stops
10	060-0380	Fuse Holder
11	NOTE	Fuse
12	060-0203	Crimp
13a	060-0097	Audible Alarm
13b	309-0061	Bracket
13c	054-0361	O-ring
14	060-0209	Transformer
15a	060-0710	Selector Switch Head
15b	060-0719	Selector Switch Contact
16	060-0205	Terminal
17	060-0330	Replacement Bulb for Item 4, Green Light
18	060-0202	Green Lens
19	060-0502	Yellow Light Assembly – Includes Fixture, Bulb and Lens (Note: Lens may also be ordered separately – see item 20)
20	060-0512	Yellow Lens
21	060-0329	Replacement Bulb for Lights (items 19)

NOTE: State Model # and Serial # when ordering replacement parts.




Figure 25: Three Phase Control Panel

ITEM NO.	PART NO.	DESCRIPTION
1	060-0233	Electrical Enclosure
2	060-0772	Red Light Assembly – Includes Fixture, Lens and LED's (Note: Lens may also be ordered separately- see item 3)
3	060-0773	Red Lens
4	060-0201	Green Light Assembly – Includes Fixture, Lens and Bulb (Note: Lens may also be ordered separately – see item 17)
5	250-2377	Decal
6	060-0553	Timer
7	060-0551	Relay
8	NOTE	Terminals
	060-0463	Ends
	060-0466	Makers
	060-0464	Stops
9	060-0380	Fuse Holder
10	NOTE	Fuse
11	060-0203	Crimp
12	060-0097	Audible Alarm
13a	NOTE	Transformer
13b	309-0061	Bracket
13c	054-0351	O-ring
14a	060-0719	Selector Switch Contact
14b	090-0710	Selector Switch Head
15	060-0205	Terminal
16	060-0330	Replacement Bulb for Item 4, Green Light
17	060-0202	Green Lens
18	060-0502	Yellow Light Assembly – Includes Fixture, Bulb and Lens (Note: Lens may also be ordered separately – see item 19)
19	060-0512	Yellow Lens
20	060-0329	Replacement Bulb for Lights (item 18)
21	060-0289	Reset Push Button
22	060-0381	Midge Fuse Holder
23	NOTE	Contactor
24	NOTE	Overload

NOTE: State Model # and Serial # when ordering replacement parts.

DELUXE OUTSIDE LIGHT REPLACEMENT PARTS **USE ONLY GENUINE PENTALIFT REPLACEMENT PARTS**





Figure 26: Outside Light Replacement Parts

<u>ITEM NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	060-0529	Housing
2	060-0702	Red LED Module
3	060-0703	Green LED Module
4	060-0524	Mounting Gasket
5	060-0701	Complete Unit (Includes items 1 – 4)

NOTE: State Model # and Serial # when ordering replacement parts.

REPLACEMENT SIGNS



<u>ITEM NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	250-1900	Exterior Driver Sign
2	250-1901	Exterior Driver Sign – Mirror
3	250-1904	Interior Shipper/Receiver Sign

LIST OF ILLUSTRATIONS

Figure 1: Safety Labeling.....	
Figure 2: Draw Pull Forces	
Figure 3: Shim Locations	
Figure 4: Remove / Replace the Guard Assembly	
Figure 5: Weld Locations	
Figure 6: Power Unit and Control Panel	
Figure 7: Conduit / Outside Light / Outside Sign Locations.....	
Figure 8: Extension Shim Locations	
Figure 9: Optional Extension	
Figure 10: Inside Light Red	
Figure 11: Restraint Lowered	
Figure 12: Inside Light Green	
Figure 13: Vehicle in Position	
Figure 14: R.I.G. Not Secure	
Figure 15: Inside Light Red and Alarm Sounding.....	
Figure 16: Inside Light Yellow	
Figure 17: Secure Vehicle by Other Means	
Figure 18: Lubrication Points	
Figure 19: Time and Mode Settings	
Figure 20: Setting the Down Travel Limit Switch.....	
Figure 21: Setting the Signal Bar Limit Switch	
Figure 22: Raised Height Adjustment.....	
Figure 23: Replacement Parts	
Figure 24: Single Phase Control Panel	
Figure 25: Three Phase Control Panel	
Figure 26: Outside Light Replacement Parts	
Figure 27: Replacement Signs	

Direct and indirect costs of an industrial accident at the loading dock can easily exceed \$100,000 and result in increased insurance costs.

Pentalock HFR32 Safety System reduces the potential for such an accident.

Pentalock HFR32 Safety System offers rugged design, simple and reliable hydraulic operation, minimal maintenance and optimum product value. The loading dock has been rated as one of the most hazardous areas within most facilities. Serious loading dock accidents can result from such things as premature truck departure, trailer creep and collapsing landing gear on loaded trailers. The Pentalock HFR32 Vehicle Restraint is a proven solution to loading dock safety concerns. The reliable hydraulic operation promotes continued use by the dock attendant. The 10-1/2" lowered height accommodates new trailers with increasingly lower rear impact guards (R.I.G.).

Features and Components: Pentalock HFR32 Safety System

Hydraulic operation ensures that the restraint will function reliably, in the toughest environments. This is very important in the harsh environment that most restraints are subjected to. Hydraulic systems have been proven to be extremely reliable. Due to this, hydraulic systems are the activation method of choice in industries such as aircraft and heavy construction equipment. The use of hydraulics on a vehicle restraint eliminates problems associated with relying on external electric motors, linear activators and / or gas spring operation that are incorporated by other manufacturers.

resistant, standard
and construction
ensures reliable operation
after unit has been
tested. Other
manufacturers offer this
as an option or not

10-1/2 inch Lowered Height facilitates "No impact" operation. Accommodates new lower vehicle Rear Impact Guards and meets 1998 NHTSA rear impact guard bar regulations for trailers.

Signal Bar requires approximately 30 lbs of pressure to activate, thereby eliminating false engagement signal.

32,000 lb Restraining Capacity

Side-by-side hook
arrangement effectively
increases the rear impact
holding strength and
restricting capacity of
restraint.

PTFE bushings in
combination with Hard
Chrome plated pins for
reduced maintenance, on
all pivot points.

Heavy - Duty mounting
plate ensures simple yet
secure installation.

Watertight and
corrosive duty limit
switches.



PSI yield high
strength steel on structural
d hooks.

Return spring ensures
positive retraction of
locking assembly.

Note: Restraint is shown in a partially
raised position

structural guard protects the hook arrangement and hydraulic cylinder from impacts such as snow removal equipment and trucks. "Open" design allows dirt and debris to naturally move away from restraint components as opposed to competitive


Communication System Components



Interior sign directs lift truck operator to load/unload on green light signal only.


Exterior high visibility, LED Deluxe lights and dual image safety yellow instruction signs are provided as standard. Narrow width of light and signs facilitates easy installation between dock seal side pads. LED lights ensure long reliable operation.

Control Panels




EMA 12 interior wall mount control station. High visibility interior signal lights are coordinated with exterior signal lights. Clear, concise and easy to follow instructions guide dock attendant how to use the system.

Selector switch and amber light accommodate "override" mode. UL certified for the design and manufacturer of industrial control equipment.



Combination control panels combine the controls for loading dock equipment such as Vehicle Restraint System, Hydraulic Dock Leveler, Overhead Door and Inflatable Dock Seal into a single common panel. This ensures proper use and sequencing of equipment for increased safety and ease of operation. PLC activation is available for more complex interlocking and sequencing.

Reliable Hydraulics



Hydraulic power unit is compact and easily installed on the interior wall of loading dock or under the dock leveler. Internal wall mount installation safely positions motor/pump assembly away from the elements, condensation and potential impact of an incoming vehicle.


When purchased in conjunction with a Pentaplift Hydraulic Dock Leveler, the operation of the Pentaplift HFR32 Hydraulic System and Hydraulic Dock Leveler are combined into

Pentalock HFR32's 32,000 lb pull rating offers protection against:

- Unscheduled truck / trailer departure
- Excessive trailer creep
- Landing gear collapse

Pentalock HFR32 Safety System Minimizes the Potential of Dangerous False Signals


The primary concept of a vehicle restraint system is to engage and hold a truck/trailer communicating the loading/unloading status to the truck driver and the lift truck operator. The design of many competitive vehicle restraints can cause them to indicate that a truck/trailer is restrained when in fact, it is not. An incorrect signal is more dangerous than no signal at all since it defeats the primary purpose for using a vehicle restraint system. A major advantage of the Pentalock HFR32 Vehicle Restraint is its signal bar, which minimizes the potential for a false signal. This bar is positioned directly under the area where the R.I.G. should be when it is engaged. The signal bar ensures the R.I.G. is properly engaged before it activates the light on the inside control panel. With other restraint designs, if the tip of the locking member contacts something under the truck, or if the locking member doesn't rise or rotate, the restraint can falsely signal that the truck/trailer is engaged. Pentalock HFR32 Vehicle Restraint's signal bar ensures that this can't happen.



Competitors locking member under R.I.G. (improperly restrained)

Pentalock HFR32 Safety System Operation is operator Controlled

Non-impact operation of the Pentalock HFR32 Vehicle Restraint ensures long trouble free performance and eliminates damage to the restraint system or incoming vehicle's rear impact guard. Other non-impact models are available, but the Pentalock Model HFR32 Vehicle Restraint provides a structural impact guard as standard equipment. The structural guard withstands accidental contact to the operating components caused by unusually low incoming vehicles and trucks. The compact design reduces the projection from the dock face as well as the height of the restraint, thereby minimizing the risk of accidental impact from incoming vehicles, exterior cross traffic or snow removal equipment.



Competitors impact operation can cause damage

Pentalock HFR32 Safety System Features

- 32,000 lb restraining capacity
- Ease of operation
- Understandable, advanced high visibility communication system
- Meets 1998 NHTSA rear impact guard bar regulations for trailers
- Low profile height of 10 1/2"
- Operation range of 10 1/2" to 28 1/2"
- Dual side-by-side hook arrangement effectively increases the rear impact guard holding strength and the maximum restraining capacity of the restraint
- Open structural guard allows dirt and debris to naturally move away from restraint components as opposed to competitive designs with boxed in housings that retain and hold dirt and debris that fall into the restraint. The boxed in housing causes cleaning of the restraint to be more involved and more frequently
- Heavy-duty structural components
- Reliable, low-maintenance hydraulic operation
- Audible alarm
- Interlocking capabilities with other dock equipment
- Watertight and corrosive duty limit switches ensures reliability

Available Options include: Zinc Plated Finish, Pit Extension plate and Cast in concrete weld plate.

© photos may reflect products with optional features. All Pentalift Equipment products are subject to design improvement through modification without notice.

PENTALIFT EQUIPMENT CORPORATION

1510 Buffalo NY U.S.A. 14240-1510
1060 Guelph ON Canada N1H 6N1

Phone: (519) 763-3625 Fax: (519) 763-2894
Phone: (519) 763-3625 Fax: (519) 763-2894

NO. 1091 P. 33

PENTALIFT EQUIPMENT CORPORATION WARRANTY

WARRANTY

Pentalift Equipment Corporation expressly warrants that any product manufactured by Pentalift Equipment Corporation will be free from defects in material and workmanship under normal use for a period of one (1) year from the date of shipment of the equipment, provided the original purchaser maintains and operates the product in accordance with proper procedures. In the event the product proves defective in material or workmanship, Pentalift Equipment Corporation will at its option:

1. Replace the product or the defective portion thereof without charge to the purchaser; or
2. Alter or repair the product; on site or elsewhere, as Pentalift Equipment Corporation may deem advisable, without charge to the purchaser.

The warranty stated in the previous paragraph is that expressed by PENTALIFT EQUIPMENT CORPORATION AND IS IN LIEU OF ALL WARRANTIES AND WARRANTIES, EXPRESSED OR IMPLIED BY ANYONE OTHER THAN PENTALIFT EQUIPMENT CORPORATION. This warranty does not cover any failure caused by improper installation, misapplication, overloading, abuse, negligence, or failure to lubricate and adjust or maintain the equipment properly and regularly. Parts requiring replacement due to age resulting from abuse, improper operations, improper or insufficient lubrication, lack of proper protection or vehicle impact are not covered by this warranty. Pentalift Equipment Corporation assumes no responsibility or liability for:

1. Consequential damages of any kind which result from use or misuse of the equipment.
2. Damage or failure resulting from the use of unauthorized replacement parts.
3. Damage or failure resulting from modification of the equipment.
4. Damage resulting from the misuse of the equipment.

THERE ARE NO WARRANTIES, EXPRESSED OR IMPLIED, WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. THERE IS NO WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE.

Pentalift Equipment Corporation warranties extend only to the original product itself. In no event shall Pentalift Equipment Corporation be responsible for or liable to anyone, including third parties, for special, indirect, collateral, punitive, incidental or consequential damages, even if Pentalift Equipment Corporation has been advised of the possibility of such damages. Such excluded damages include, but are not limited to, loss of good will, loss of profits, loss of use, interruption of business or other similar indirect loss.

Pentalift Equipment Corporation DISCLAIMS all liability arising out of the workmanship, methods and materials used by the installer.

Pentalift Equipment Corporation DISCLAIMS all liability for premature product wear, product failure, property damage or bodily injury from improper installation and application.

Pentalift Equipment Corporation will not accept any warranty for which the original purchaser does not notify Pentalift Equipment Corporation's Warranty Department of the defect within ninety (90) days after the product defect is discovered. A fully completed Registration Card is required prior to the review or processing of any warranty requests or claims.

WARRANTIES, whether expressed or implied, relating to workmanship and materials used in connection with the installation of Pentalift Equipment Corporation products are specifically DISCLAIMED.

WR001R02



P.O. Box 1510, Buffalo, NY, U.S.A. 14240-1510
Phone: (519) 763-3625 • FAX (519) 763-2894
P.O. Box 1060, Guelph, ON, Canada N1H 6N1
Phone: (519) 763-3625 • FAX (519) 763-2894
www.pentalift.com

Pentalift Equipment Corporation products are subject to design improvement through modification without notice.

EQUIPMENT CORPORATION